

## Stamisol® – Connectors for roof windows

With the Stamisol® connection strip.

Important:

Fitting the roof window is a very complex process and should only be carried out by a skilled professional.

### Installation instructions

Pos. 755

Pos. 755.270-274

Pos. 785.140-145

Pos. 755.340-345

### Installation instructions

Fully assemble the roof window and fit it into place. Work from the bottom upwards with the Stamisol® connector.

Fix the Stamisol® connection strip to the top edge of the window. The corners should be cut in the form of a cross.

The overlaps must be glued with the Stamisol® glue. The lateral components must be assembled in the same way. The corners must be cut and folded with great precision. The upper connection must be covered in such a way so as to prevent water from penetrating at the corners.

If flow-back is a risk: seal the joint with Stamisol® corner pieces.

See the assembly instructions that come with the packaging.

On the inside, fit the ABS or SD 70 vapour breaks to the roof window so that they are completely sealed.

### Planning reference

The installation specifications must be respected.

We recommend that you use the window connection kits supplied by the following companies:

Roto Frank SA

8953 Dietikon, Tel: 01 745 85 45

HP. Gasser SA

6078 Lungern, Tel: 041 679 70 70

**Planning and execution: according to SIA 238  
New SIA 232**

