

Stamisol® DW – for industrial roofing with a metallic covering

Various system suppliers.

1. **Profiled metallic covering**
2. **Untreated wooden wainscoting installed at a distance of 5 to 10 mm**
3. **Cross laths with joints for nailing (ventilation space)**
4. **Stamisol DW**
5. **Various installation systems**
6. **ABS ou Stamisol® SD 70 vapour breaks**
The overlaps and connections should be glued using the Stamisol® self-adhesive strips so that the air seal is tight.
If necessary, fix the wall connections using the butyl rubber or, for example, with Sikaflex 11FC.
7. **Space left for the electric cables**

Tender text reference

Stamisol® DW
Pos. 720.721
Pos. 721.171

ABS

Pos 520
Pos 524.100
Pos 524.134

SD 70

Pos 530
Pos 534.100
Pos 534.121

Planning reference

Stamisol® DW can be installed and glued both horizontally and vertically.

The specifications given by the suppliers of the system must be respected.

Depending on the layout of the building, the vapour breaks will have to be adapted to the construction of the roof in question.

Installation instructions

The instruction specifications must be respected.

The entire thickness of the rafters must be entirely insulated (in line with the recommendations of the insulation manufacturer).

Planning and execution: according to SIA 238
New SIA 232

